Guide | OpenEnergyMonitor


4. Log Remotely

« Previous step: Log Locally


Next step: Dashboards »

Data can also (optionally) be posted remotely to <u>Emoncms.org</u>. Posting data remotely has the advantage of being able to easily access your data from anywhere on the web without having to open access to your local emonPi:


1. Create Emoncms.org account



- Browse to <u>Emoncms.org</u>
- Create account or log-in with existing account
- Select Inputs > Input API helper (https://emoncms.org/input/api)
- Copy Read-Write API key



2. Enter API key into local Emoncms



- Log-in to local Emoncms on your local network e.g. http://emonpi or http://192.168.X.X
- Navigate to Setup > emonHub
- Scroll down the emonHub config, in the [[emoncmsorg]] section pate in your Emoncms.org R/W API key overwriting the xxxxxxxxxxxxxx value.
- Hit Save

Advanced emonhub.conf configuration guide

3. Setup Emoncms.org Input Processing

- Log back into Emoncms.org
- Inputs from emonPi should be visible on the Inputs page
- Log Inputs to Feeds in the same way as <u>Local Emoncms Logging</u>

If no appear in Emoncms.org emonHub.log on emonHub page of Local Emoncms for debugging

Posting to multiple Emoncms accounts

The emonPi can post to other remote Emoncms accounts as well as or instead of emoncms.org. To post to another Emoncms account create another EmonHubEmoncmsHTTPInterfacer section in emonhub.conf e.g:

Multiple emonPi's posting to a single Emoncms.org account

It's possible to setup multiple emonPi's posting to a single Emoncms.org account, this is useful if you want to monitor several installations with a single login. By defaut data from sensors connected directly to the emonPi are tagged in Emoncms with **node ID 5**. If multiple emonPi's are posting to the same account we need to set a different node ID to each emonPi.

1. Change emonPi node ID

The emonPi's node ID can be changed in the *EmonHub Config Editor*. Login to *local Emoncms then browser to Setup > EmonHub, in the [interfacers] section change baseid = 5 to a different number: 4, 3, and 2 are recomended since these node ID's are not already allocated:

EmonHub Config Editor

```
Save
[[RFM2PI]]
   Type = EmonHubJeeInterfacer
   [[[init_settings]]]
     com_port = /dev/ttyAMA0
     com_baud = 38400
                                     # 9600 for old RFM12Pi
   [[[runtimesettings]]]
     pubchannels = ToEmonCMS,
     subchannels = ToRFM12,
     group = 210
     frequency = 433
    baseid = 5
                                # emonPi / emonBase nodeID
     quiet = true
                               # Report incomplete RF packets (no implemented on emonPi)
     calibration = 230V
                                  # (UK/EU: 230V, US: 110V)
     # interval = 0
                                # Interval to transmit time to emonGLCD (seconds)
[[MQTT]]
   Tyne = EmonHuhMattInterfacer
```

2. Update emonPi Node Decoder

After changing the emonPi node ID we also needto update the EmonHub node decoder to enablelocal Emoncms to decode the data from the emonPi with the updated node ID. To do this scroll further down the emonhub config page to the [Nodes] section and change [[5]] to the new emonPi node ID e.g. 5, 3, or 2. Then click Save to save changes.

See here for detailed emonhub config documentation.

To start the emonPi's posting to the same emoncms.org account paste in the same Emoncms.org read-write API key into each emonPi's emonhub config file as detailed above.

Next step: Dashboards »

Edit on GitHub
Edit on GitHub Prose

Contents

- Setup
 - 1. System Overview
 - o 2. Connect
 - <u>3. Install</u>
 - 4. Log Locally
 - <u>5. Log Remotely</u>
 - 6. Dashboards
 - 7. Add Energy Sensing Node(s)
 - <u>8. Add Temperature Node(s)</u>
 - 9. Add Optical Pulse Sensor
 - 10. Import / Backup
 - 11. Use in North America
 - 12. Troubleshooting
- Emoncms
 - Daily kWh
 - Daily Averages
 - Exporting CSV
 - <u>Histograms</u>
 - Emoncms API
- Applications
 - Home Energy
 - Solar PV
 Hoatour
 - Heatpump
- Integrations
 - OpenEVSENode-RED
 - OpenHAB
 - Control Relay
 - <u>LightWave RF Control</u>
- Technical
 - Overview
 - Specifications
 - Service Credentials
 - MOTT
 - Firmware Modification

- Resources
- Support
 Community Forum
 Contact

Website powered by <u>Jekyll</u> and <u>Oscalite</u>. Hosted by <u>GitHub</u> and served by <u>CloudFlare</u>.