


Mood Remote Operation Manual

Model No: JSJS LW104

It is important to install this product in accordance with the fitting instructions below. Failure to do so may render your guarantee void.

IMPORTANT: PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE AND FOR GUIDANCE ON THE ASSOCIATION OF REMOTE HANDSETS. FOR HELP AND SETUP GUIDANCE PLEASE VISIT www.lightwaverf.com

OVERVIEW:



SETUP:

The functions illustrated here relate to the operation of ON/OFF receivers such as Single and Double Sockets and the Plug-in Adapter Sockets, and to dimmable receivers; for information regarding how to pair the handset to the relevant receiver(s), please refer to the setup instructions for that individual device.

Before operation, ensure that the plastic film isolating the battery is removed (see later battery replacement diagram for guidance on how to access battery).


NOTE: If the RF range between the transmitter and receiver is too great to achieve reliable operation, the LightwaveRF Connect SIGNAL BOOSTER may be used in conjunction with this product to increase the signal strength over greater distances.

IMPORTANT: On the Mood Remote there is a slider labelled **ABCD**. Sliding between the letters allows you to pair LightwaveRF devices to separate channels (A,B,C or D). Which ever position the slider is in when you pair the remote to the LightwaveRF device it will be paired to THAT channel. You can then turn your devices on or off independently using the same set of on/off keys with the slider in the relevant position. You can also pair multiple devices to the SAME channel. Every device that you pair to the remote will become part of your mood selections regardless of which channel it is paired to.

OPERATION :

'ON' Button - Press once to switch paired devices 'ON'.
Hold to raise dim level.

'OFF' Button - Press once to switch paired devices 'OFF'.
Hold to lower the dim level.



Setting Moods Using the Mood Remote

1. Ensure that LightwaveRF devices (CFRs /dimmers/ sockets etc.) that you wish to include in the 'mood' are paired with the Mood Remote (they can be paired to any channel - A,B,C or D).
2. Using the Remote, or via manual control, set the status (on or off) and dim level of the devices that you want to include in the mood.
3. When you are satisfied with the current setup, **press and hold** one of the Mood buttons. The LEDs on any devices paired with the Mood Remote will flash to indicate that the Mood is now set.
4. Press the 'All Off' Button to turn off the mood. To return to the saved mood at any time simply press the relevant mood button once again.
5. Repeat the process for other mood buttons to create multiple mood settings.

SPECIFICATION:

RF frequency: 433.92 MHz

Battery: 3V CR2032 lithium cell battery operated
(included)

Blue LED indicator



J S J S D E S I G N S P L C

Birmingham Science Park Aston
Faraday Wharf
Holt Street
Birmingham
B7 4BB

Tel: 01902 500 562

Email: support@jsjsdesigns.com