



Need help?

We're here to help you have a great Nubo experience.
Please contact us at www.nubocam.com/support

Warranty disclaimer :

Services, features and storage capabilities are dependent on wireless service facilities, covered telecom network services and your Panasonic Nubo Services subscription. Please go to www.nubocam.com for registration and subscription.

The provided simcard is simlocked and only usable for Panasonic Nubo Services after registration and subscription at www.nubocam.com.

Please refer to www.nubocam.com for all safety guidelines and terms & conditions.

Panasonic Cameramanager B.V. hereby declares that Nubo is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Copy available via support@nubocam.com

CE 0168



Infrared light

See in the dark


Lens

Wide-angle lens

Motion Sensor

Microphone & Speaker

Two-way audio.



LED - indications:



Blue - Blinking

Your Nubo is booting-up



Blue - Bright

Motion sensor is detecting movement



Blue

Camera is on and connected



Green - Blinking

Nubo is in Ad hoc Wi-Fi mode




LED Off

Power is off



Red - Blinking


Power supply is too low to power up



Magnet

Stick your Nubo on almost any metal surface using the magnet.

Reset button



SD slot

SD / SDHC / SDXC
up to 128GB

Micro USB

Sim slot



Screwdriver



Let's get started!
Just 3 easy steps.