

Thermostatic Radiator Valve (TRV)

Model No. LW922

Features

- · RF controllable TRV head
- Smartphone control (requires Lightwave Link)
- · Monitor and control temperatures in realtime
- Create automatic schedules
- · Control remotely from anywhere
- · Create zoned heating
- Screw fits standard thermostatic valves
- Adapters included for different valve types
- Battery powered (2 x AA)
- · Manual on / off control
- 1 hour manual boost function



LightwaveRF App showing TRVs controlling separate areas.

Specification

RF frequency: 868 MHz

Batteries: 2 x AA

Valve type: Standard thermostatic. Adapters

included for vatiations in diameter.

Clearance: Min. 20mm between valve seat and wall

Warranty: 2 year standard warranty

